

To explore
our range of products
and recipes log on to
www.ushacook.com



CITRUS PRESS JUICER



USHA care | Toll Free: 1800 1033 111

usha_care@usha.com

USHA INTERNATIONAL LTD.

Plot No. 15, Institutional Area, Sector 32, Gurugram - 122 001 (Haryana)

Tel : +91-124-4583100, Fax : +91-124-4583200, E-mail: usha_care@usha.com , Website: www.usha.com

Regd. Office : Surya Kiran Building, 19 Kasturba Gandhi Marg, New Delhi 110 001, (India) Tel : +91 11 23318114 Fax : +91 11 23318118

ISO 9001 : 2015 Certified Company



Dear Customer,

Congratulations!

You are now a Proud Owner of an USHA iJuice Citrus Press Juicer.

Innovatively designed, using only the highest quality material and components for years of trouble free performance.

Please read these instructions carefully before using.

Best Wishes

CONTENTS

Safety instructions	2
Know your product	3
Operating instructions	4
Cleaning and maintenance	5
Product technical specifications detail	5
Troubleshooting	5
Warranty card	6



2 WAY ROTATION



DUAL SIEVE



DIFFERENT CONES



LOW-SPEED CRUSHING


SAFETY INSTRUCTIONS

Before using the electrical appliance the following basic precautions should always be followed including the following:

1. Read all instructions before using.
2. Before using check that the voltage of the socket corresponds to the one shown on the appliance nameplate / rating plate.
3. To protect against the risk of electrical shock do not put the motor unit in water or other liquid.
4. Unplug the Appliance from the outlet when not in use, before Assembly/Disassembly, and before cleaning.
5. Do not operate the appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Take the appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.
6. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
7. Place the appliance on a flat surface. Do not place on or near a hot gas or electric burner, or in a heated oven.
8. Do not let the supply cord hang over the edge of the table or counter.
9. Close supervision is necessary when the appliance is used by or near children.
10. Do not use appliances for other than intended use.
11. The appliance can only be used to squeeze the citrus fruit, never use it for juicing other kinds of fruits.
12. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
13. Children should be supervised to ensure that they do not play with the appliance.
14. Do not use outdoors.
15. This appliance is intended to be used in households and similar applications such as:
 - staff kitchen areas in shops, offices, and other working environments
 - farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.
16. Warning: Potential injury from misuse.
17. Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.
18. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instructions concerning the use by a person responsible for their safety.

HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS

KNOW YOUR PRODUCT



OPERATING INSTRUCTIONS

Before the first use, Clean the top Cover, Juicer Cones, Mesh, and Bowl thoroughly with warm water.

1. Place the Spindle Shaft on the Base followed by Bowl, then assemble the mesh into the spindle Shaft, after assembling the small Cone into the Mesh, Finally assemble the Big Cone onto the Small Cone.
2. Halve the fruit, put the fruit on the Cones, and press it lightly and the motor starts running. Then the extracted juice will flow into the cup through the mesh, and the rough flesh and pith will remain on the sieve. The motor may rotate in any direction (Clockwise/ anticlockwise) as you press the fruit against the cone.

! Caution:

Never exert excessive force when pressing the fruit to prevent it from blocking and damaging the motor.

3. Once completing the squeezing, release the hand from the Cones and the motor stop running. The appliance is in an idle state. You may restart it again at any time by pressing the Cones down.
4. After extraction of juice, Disassemble the Cones and then pour the juice.

! Caution:

The appliance shall be ON 15 seconds, OFF 15 seconds, and after 10 consecutive cycles, the appliance must be cooled down for 30 minutes.

Note: The max capacity of the Bowl is 1L. Make sure not to overfill the Bowl

5. When the operation is completed or the appliance is not in use, unplug the appliance.
6. If you wish to keep the juice in the Bowl, make sure that the top lid is in place for keeping it clean & hygienic. It is advised not to keep the juice in the bowl for a long time.

! Caution:

When the juicer is not in use, never hold the two pins of the plug and turn the Cones by hand as this may result in electric shock.

CLEANING AND MAINTENANCE

1. Unplug the appliance and wait for it to completely cool down before cleaning.
2. Remove the Cones, Mesh and Bowl. Clean them in hot, soapy water. Then rinse under running water and wipe dry.
3. Wipe the rotating Shaft and Motor unit with a soft, damp cloth.

! Caution:

Never use metal polish for cleaning and do not put parts into the dishwasher to clean. Never Put the Power Base into water or any other liquid

4. Assemble all parts and store them in cool dry place with proper ventilation.

PRODUCT TECHNICAL SPECIFICATIONS DETAIL

Model no	iJuice Citrus Press Juicer
Power	30 W
Voltage / Frequency	230 V AC / 50 Hz
Accessories/ Parts	Top Cover, Two Cones, Sieve Assembly, Bowl, Shaft

Note:

In view of the USHA policy of continuous improvement. Specification may change without notice.

TROUBLESHOOTING

If your citrus juicer malfunctions or fails to operate, check if the appliance is plugged in properly or check the wall socket. Try unplugging the appliance and then plugging it back. Other than the recommended cleaning, no further user maintenance should be necessary. If for any reason your citrus juicer should require repairs, do not try to fix it yourself. Please contact your nearest Authorized Service Centre or call at **USHA CARE** toll-free number 1800-1033- 111.

